PHOENIX

AirMAX & AirMAX Pro

QUICK START GUIDE

Thank you for purchasing a Phoenix AirMAX Air Mover. Please follow these steps to successfully setup and operate your new air mover.

For a complete manual, scan this QR code.

For the AirMAX Pro, scan this QR code to view the Smart Equipment Activation Guide

STEP 1

Set your AirMAX in one of the three operating positions.



Flat



On its side



Toward the ceiling

STEP 2

Plug in your AirMAX. You can plug additional units into the convenience plug with a maximum of six units on a 15 amp circuit.

STEP 3

Turn on the power switch.

AFTER THE JOB

Unplug the unit. Wrap the cord around the indent on the side of the unit. Use the cord lock to secure the cord. Stack units to conserve space on your truck.



⚠WARNING

Not Suitable for use with Solid-State Speed Controls.
Disconnect the unit from power before servicing or cleaning. Replace all safety grills after servicing or cleaning.

AVERTISSEMENT: Débranchez l'appareil de l'alimentation électrique avant les travaux d'entretien ou de nettoyage. Remplacez toutes les grilles de sécurité après l'entretien ou le nettoyage.
AVERTISSEMENT: Ne Convient Pas a Des Regulateurs De Vitesse a Semi-Conducteurs
WARNING: DO NOT use or store this device in an area that is accessible to children.
AVERTISSEMENT: NE PAS utiliser ou stocker cet appareil dans une zone accessible aux enfants.

AirMAX & AirMAX Pro

LIMITED WARRANTY

Warrantor:
Therma-Stor LLC
4201 Lien Rd
Madison, WI 53704
Telephone: 1-800-533-7533

Who Is Covered: This warranty extends only to the original end-user of the Phoenix Air Mover, and may not be assigned or transferred.

First Year Warranty: Therma-Stor Products warrants that, for one (1) year the Air Mover will operate free from any defects in materials and workmanship, or Therma-Stor Products will, at its option, repair or replace the defective part(s), free of any charge.

End-User Responsibilities: Warranty service must be performed by a Servicer authorized by Therma-Stor Products. If the end-user is unable to locate or obtain warranty service from an authorized Servicer, he should call Therma-Stor Products at the above number and ask for the Therma-Stor Products Service Department, which will then arrange for covered warranty service. Warranty service will be performed during normal working hours.

The end-user must present proof of purchase (lease) upon request, by use of the warranty card or other reasonable and reliable means. The end-user is responsible for normal care. This warranty does not cover any defect, malfunction, etc. resulting from misuse, abuse, lack of normal care, corrosion, freezing, tampering, modification, unauthorized or improper repair or installation, accident, acts of nature or any other cause beyond Therma-Stor Products' reasonable control.

Limitations and Exclusions: If any Air Mover part is repaired or replaced, the new part shall be warranted for only the remainder of the original warranty period applicable thereto (but all warranty periods will be extended by the period of time, if any, that the Air Mover is out of service while awaiting covered warranty service).

UPON THE EXPIRATION OF THE WRITTEN WARRANTY APPLICABLE TO THE AIR MOVER OR ANY PART THEREOF, ALL OTHER WARRANTIES IMPLIED BY LAW, INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL ALSO EXPIRE. ALL WARRANTIES MADE BY THERMA-STOR PRODUCTS ARE SET FORTH HEREIN, AND NO CLAIM MAY BE MADE AGAINST THERMA-STOR PRODUCTS BASED ON ANY ORAL WARRANTY. IN NO EVENT SHALL THERMA-STOR PRODUCTS, IN CONNECTION WITH THE SALE, INSTALLATION, USE, REPAIR OR REPLACEMENT OF ANY AIR MOVER OR PART THEREOF BE LIABLE UNDER ANY LEGAL THEORY FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES INCLUDING WITHOUT LIMITATION WATER DAMAGE (THE END-USER SHOULD TAKE PRECAUTIONS AGAINST SAME), LOST PROFITS, DELAY, OR LOSS OF USE OR DAMAGE TO ANY REAL OR PERSONAL PROPERTY.

Some states do not allow limitations on how long an implied warranty lasts, and some do not allow the exclusion or limitation of incidental or consequential damages, so one or both of these limitations may not apply to you.

Legal Rights: This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

WARRANTY REGISTRATION CARD

IMPORTANT WARRANTY INFORMATION - DO NOT DISCARD

REGISTER YOUR PRODUCT.

WARRANTY

SERIAL NUMBER ▶

PART NUMBER ▶

www.thermastor.com/registration

WARRANTY

Register your product using the serial number and part number above at www.thermastor.com/registration

This is important Warranty Information. Please DO NOT DISCARD!